



Guru Ram Das Ashram


CLEANING THE AIRCONDITIONING FILTER

Instructions refer to the 3 AC units on the ground level.

'Main Unit' refers to AC in the front half of the Main Room.

'Secondary Units' refer to the Kitchen AC unit and AC unit in back half of main room. They are the same model.

Units can remain ON during cleaning.



Lift front flap to reveal the filters.



Remove filters by sliding them out.



There are two filter slides on each unit.



Main Unit: Felt is freed from frame contained within filter slides.



Secondary Units: Remove felt filters after removing filter slides



Remove dust and dirt with water. Kitchen sprayer works well



Dry felts and slides, and replace them. You are done! Thank You!!!